Hardwa	re Kit (rowing version	, two stations)	
QTY		USE	UOM
50		painter and foot rests	ft
1	R P	oarlocks: choose between horn or oval	pr
12		lanyards for oarlocks	ft
2		oarlocks (optional to use top-mount but requires hardwood blocks)	pr
0.5	C C	bow eye (screw)	pr
2		bow eye strap (not for towing) [1]	ea
16	Contraction of the	oarlock sockets	ea
4		forward fixed seat	ea
4	\mathbf{i}	Bow seat fixed	ea
25	No. of Concession, Name	bow/stern seats (Rowing version only) [2]	ea
12.167		Cut from 12' - keel-1-24" w/ bend, 2-39.5", 3-32.5") + skeg (47.5" w/ bend) , stem (14.5"), Incl. one extra 11"	ft
1	Deserve	half oval screws	box
21		Rubrails at bow and stern (8), midship frame to trunk (1), side arms to bottom frame (6 per frame)	ea
8	and the second s	transom into knees, keel to bottom, skeg	ea
3	Car Barrows	skeg from inside boat	ea
1		bedding hardware	ft
0.75			ea
Sailing	version hardware		
2		buoyancy tank aft	ea
2		rudder hardware	ea
2		rudder hardware	ea
1	4	rudder	ea

8	6	washers for transom gudgeon fasteners	еа
14		pintle/gudgeon	ea
14		pintle/gudgeon	ea
14	6	pintle/gudgeon	ea
2	· · ·	mast partner	pr
5		mast partner bolts	ea
5		mast partner	ea
5	6	mast partner	ea
0.5	ST P	mast partner	pr
1		mast gate quick release	ea
1	a free	mainsheet traveller, screwed to inwales	pr
1	\bigcirc	outhaul to clew hook	ea
1		outhaul	ea
1		downhaul	ea
1		halyard	ea
6		for nylon cleats	ea
12			ea
1		halyard	ea
2		RF59	ea
2		for CL236 Clamcleat (downhaul)	ea
5		RF59	ea
4	0	RF59, Clam cleat (downhaul)	ea
1		bushing for #8 tiller bolt, 1"	ea
1	Ň	tiller bolt	ea
1		tiller bolt	ea
1	O	tiller bolt	ea

1		downhaul bolted to port side of partner or step	еа
1		downhaul lashed to boom near mast	ea
2		mainsheet blocks	ea
1	0	mainsheet to traveller	ea
30	The second	corner lashings, reef lines	ft
35	Chu Chu	downhaul, painter	ft
25		mainsheet	ft
6		mainsheet traveller	ft
30		halyard	ft
4		daggerboard bungee	ft
2		tiller extension	ft
1		for shaping daggerboard and rudder	pair
69		8 x 6"	ea
1			hr
Ungrado	es available		
opgrade			
1			
33			
2			bx
2			bx
	ving station		
1			еа
1			ea
8			еа
1			ea
10			ea

[1] screws are sufficient for tying off to a dock, but if intending to tow behind a boat, use through bolts

[2] Only needed if doing slatted, Pine seats